


T70 Series Components List

Part Description	Part Number
Blower Motor, Condenser	10-1020-32
Blower Motor, Evaporator	10-1020-27
Capacitor, Condenser Blower	52-6084-00
Capacitor, Evap Blower	52-6084-00
Capacitor, Compressor, Run	52-6032-05
Capacitor, Compressor, Start	10-1032-32
Coil, Condenser	70-1001-03
Coil, Evaporator	70-1002-00
Compressor	10-1026-103
Contact, Compressor	10-1005-44
Controller, Head Pressure	10-1106-108
Evap Inlet Filter	10-1000-04

Part Description	Part Number
Evap Discharge Register	62-1020-00
Filter/Dryer	52-6028-06
Grille, Condenser fan	13-1014-09
Relay, Alarm (Optional)	10-1005-62
Relay, Compressor, Start	10-1042-06
Switch, Low Pressure	52-6104-38
Terminal Block	10-1003-31
Thermal Expansion Valve	10-1040-34
Timer, Random Start	10-1005-76
Evap Inlet Filter	10-1000-04
Timer, Bypass	10-1005-58
Transformer	10-1006-95

T70 Schematic



T70 Wire Diagram

